## SEAT BASE ADAPTERS

Our patented Seat Base Adapters are your solution for added leg room and adapting after-market or OEM seats without drilling added holes into your floor! Each Seat Base Adapter is manufactured to match your specific brand of seat making installation simple. Adapters come with all mounting hardware included!





## PRODUCT INFORMATION

Part #	Seat Information	Fitment
IC199001-xx	8 in. OEM/National & Knoedler	Peterbilt 379, 386, 389
IC199001-xx	12 in. Sears Atlas WITH Riser	Peterbilt 379, 386, 389
IC199001-xx	10 in. Bostrom Pro Ride with Standard Base	Peterbilt 379, 386, 389
IC199002-xx	10 in. Bostrom Wide Ride	Peterbilt 379, 386, 389
IC199002-xx	10 in. Bostrom ProRide with Lo Base	Peterbilt 379, 386, 389
IC199002-xx	8 in. Seats Inc. Legacy LoPro (Seat Build Date Pre July 1, 2018)	Peterbilt 379, 386, 389
IC199003-xx	10 in. Seats Inc. Legacy Gold/Silver	Peterbilt 379, 386, 389
IC199006-xx	10 in. National Seating Series 2000 Ultra Ride	Peterbilt 379, 386, 389
IC199004-xx	12 in. Sears Atlas WITHOUT Riser	Peterbilt 379, 386, 389
IC199008-xx	Seats Inc. Legacy LoPro (Seat Build Date Post July 1, 2018)	Peterbilt 379, 386, 389
IC199008-xx	Legacy Pinnacle	Peterbilt 379, 386, 389
IC199010-xx	12 in. Seats Inc. Legacy Gold/Silver Series Peterbilt 579	Peterbilt 579
IC199011-xx	Seats Inc. Legacy LoPro (Seat Build Date Post July 1, 2018)	Peterbilt 579
IC199011-xx	Legacy Pinnacle for Peterbilt 579	Peterbilt 579
IC199012-xx	12 in. Sears Atlas for Peterbilt 579	Peterbilt 579
IC199013-xx	Seats Inc. Legacy LoPro (Seat Build Date Pre July 1, 2018)	Peterbilt 579
IC199013-xx	10 in. Bostrom Wide Ride for Peterbilt 579	Peterbilt 579
IC199005-xx	14 in. National Lo Profile Seat Base	Peterbilt 379, 386, 389



PATENTED

S. Bas

es la

100/00



PETERBILT FITMENT GUIDE



## FINISH OPTIONS (-xx)

Add finish option number to end of part number for desired finish. (ex: IC199001-11)

Part #	Finish
11	Billet Aluminum
12	Chrome
15	Gloss Black
16	Red Baron
17	Crystal White
18	PO Blue